

I U L living made easy

the **easy**step is a staircase which converts to a lift at the push of a button







A staircase and lift combined into just one product!

The EasyStep, which at the push of a button cleverly transforms from a set of stairs into a platform lift, is unique, providing easy and safe access to the upper or to the lower level.

The EasyStep from Easy Living Home Elevators is a safe and economical solution, to overcome accessibility requirements in both residential and commercial buildings. This is an easy to operate platform lift solution for vertical rises up to 1000mm.

Whether you are building or modifying an existing building, the EasyStep Low Rise Platform Lift is an effective way to meet accessibility requirements. Designed for both indoor and outdoor use, this lift takes up no more floor space than a normal set of stairs. No pit is required and there is no need for a separate machine room making the EasyStep very easy to incorporate into new and existing projects.

The EasyStep is a free-standing design that does not require installation against a load bearing wall, allowing a wider choice in positioning the lift.

The EasyStep is designed as the most space saving Platform Lift on the market, satisfying growing accessibility needs.



Features of the EasyStep wheelchair platform lift:

- 3 models available with 3,4 & 5 steps
- Easy to use control panel
- Quiet operation
- Indoor and outdoor applications
- No pit required
- Automatically returns to staircase position when not operated for 60 seconds
- Only Single-phase power
- Free-standing design
- Quick installation
- Battery back in case of power failure

Specifications

Model	EasyStep
Sizes available	Platform Size (mm)
Lifting height up to 555mm, 3 steps	900W x 1250L
Lifting height up to 730mm, 4 steps	900W x 1250L
Lifting height up to 1000mm, 5 steps	900W x 1550L (Suitable for commercial applications)
Maximum Carrying Capacity	250kg
Speed	0.06m/s
Travel / lifting height	Up to 1000mm
Pit Depth	No pit required
Power Supply	230 V, 10amp, single phase
On Board Control	1 Button Panel
Landing Buttons	One Standard call button per floor
Control Type	Constant Pressure
Safety First!	Alarm sounds before and during the automatic return
	to staircase mode.
	• Infra-red movement sensors monitor the area between the
	steps and under the staircase to prevent entrapment.
	If activated, movement will stop and an alarm will sound.
	 Automated ramp provides roll off protection for the wheelchair.
	Battery backup in case of power failure.
	Emergency stop button
Operation	The EasyStep automatically returns to staircase mode when
	the controls or the safety sensors have not been activated
	for 60 seconds.



Visit our showrooms

NSW. 02 8116 1500 VIC. TAS. SA 03 9094 8600 WA. 08 9322 4688 sales@easy-living.com.au

QLD. 07 3851 7500 www.easy-living.com.au

